

MODEL UH-12D/E (Turbine)  
Parts Manual Supplement

TEMPORARY REVISION 12-98-560

Group 30  
Section 31

(Insert in between pages 42 & 43)

1/5/2024

Figure & Index No	Part Number	Description	Units per Assy	Useable on Code
-1	560-3120-2	Prime Switch Box Assy (Supersedes 560-3120-2)	1	
	660-3102-2	Prime Switch Box Assy (Supersedes 560-3120-2)		
	560-3120-4	Aux. Switch Box Assy (Supersedes 560-3120-4)	1	
	660-3102-4	Aux. Switch Box Assy (Supersedes 560-3120-4)		
	560-3120-5	Aux. Switch Box Assy with Manual N2 Trim (Supersedes 560-3120-5)	1	
	660-3102-5	Aux. Switch Box Assy with Manual N2 Trim (Supersedes 560-3120-5)	1	
	560-3120-6	Prime Switch Box Assy with Manual N2 Trim (Supersedes 560-3120-6)	1	
	660-3102-6	Prime Switch Box Assy with Manual N2 Trim (Supersedes 560-3120-6)	1	
	660-3102-10	Switch Box (Replaces 28000-19A)	1	
	660-3102-13	Switch Box Decal	1	
-19	660-3101-1	Pin Retainer	1	
	560-3100-3	Pin Retainer (Alternate for 660-3101-1)		

Temp. Rev. 12-98-560